Cutting machine special purchase options

Model	Description	Illustration
CK-001 Cutting load protection function	1. If the cutting work is overloaded, the machine will stop feed for 2.5 seconds and then automatically restart feeding work. If cutting work is overloaded for consecutive three times, the automatic retracting warning light will be flashing. 2. If the electric current is overloaded, the machine will stop automatically. 3. Main motor's maximum current load can be set up and current loads status can be displayed while main motor is carrying out cutting works.	Cutting load Overload STOP 2.5sec STOP 2.5sec STOP Stop Cutting Work and Return to the Origin
CK-003 CK-003-1 CK-003-2	Outboard tank + Magnetic filtration 120L / 160L / 200L LxWxH (Replace the original standard tank)	
CK-004	Adjustable spindle rotation speed ±50% transducer is added	
CK-005	Laser projector	
CK-006	Low voltage DC24 control	